



ALPHA AND STRAND AMK INSTALLATION



STEP 1 INSTALL TWO BRACKETS MTC4091-0097-XX TO STRAND AMK USING 1/4" BOLTS, FLAT WASHERS (2EA), LOCK WASHERS, HEX NUTS, AS SHOWN




STEP 3


Α

D

- 1) INSTALL TWO BRACKETS MTC4091-0098-00 TO STRAND AMK AS SHOWN
- 2) HANG THE STRAND AMK USING TWO BRACKETS MTC4091-0098-00 TO THE ROPE AS SHOWN
- 3) INSTALL TWO BRACKETS MTC4091-0052-XX TO STRAND AMK AND ROPE USING 4 SETS OF 1/4" BOLTS,
- FLAT WASHERS, LOCK WASHERS, HEX NUTS, AS SHOWN
- 4) REMOVE TWO BRACKETS MTC4091-0098-00



STEP 2
INSTALL TWO RADIOS ALPHA TO TWO BRACKETS MTC4091-0097-XX USING 8 SETS OF M5 HEX SCREWS, FLAT WASHERS, LOCK WASHERS, HEX NUTS AND 8 SETS OF 1/4" FLAT WASHERS



FINISHED PRODUCT

	COMMSCOPE, INC. OF NORTH CAROLINA						
		STRAND AMK, ALPHA BRACKETS					
		SIZE SCALE DOCUMENT NO. 860673121-AMK-2-XX				<	
				DRAWING			SHEET
© 2024 CommScope, Inc. Confidential				VERSION 00	STATUS RE	REVISION A	2 OF 2
				1			

3

2