


DIPLEXER AND RAYCAP INSTALLATION



STEP 4

D

С

Α

DIPLEXER


INSTALL THE BRACKETS MTM1031-1601 TO THE DIPLEXER USING CAPTIVE HARDWARE


INSTALL THE DIPLEXER TO THE POLETOP WELDMENT USING 2X ROUND CLAMPS. DIPLEXER SHOULD BE APPROXIMATELY LOCATED AND ORIENTED AS SHOWN IN THE VIEWS.

RAYCAP

INSTALL THE RAYCAP TO MOUNTING BRACKET MTC391285 USING 4X 1/4" BOLTS, LOCK WASHERS.

INSTALL TO THE POLETOP WELDMENT USING 2X ROUND CLAMPS. RAYCAP SHOULD BE APPROXIMATELY LOCATED AND ORIENTED AS SHOWN IN THE VIEWS.





C) 2024 CommScope, Inc. Confidential

2

3

4

