





INSTALLATION INSTRUCTION FOR CMAX-OMF9-43-UWI53



Installation Steps

- 1) Cut a hole in the ceiling tile with the diameter shown in the left picture.
- 2) Remove the retaining nut from the back of the antenna.
- 3) Feed these two pigtails of this antenna through the hole in the ceiling tile.
- 4) Re-install the retaining nut so that it is close-fitting to the ceiling tile.

- 1) Drill two holes in the ceiling per pattern of holes in this antenna shown in the left.
- 2) Fasten the flat side of this anchors (Plastic plug $\Phi 6 \times 25 \text{mm}$) and screws (tapping screw ST4.2X25mm).
- 3) Mount this antenna to the ceiling tile.

Note:

Cable min. bending radius: 40mm

© Copyright 2020 CommScope, Inc.

All rights reserved.

All information contained in this manual has been revised thoroughly. Yet CommScope accepts no liability for any omissions or faults.

CommScope reserves the right to change all hardware and software characteristics without notice.

Names of products mentioned herein are used for identification purposes only and may be trademarks and / or registered trademarks of their respective companies.

No parts of this publication may be reproduced, stored in a retrieval system, transmitted in any form or by any means, electronic, mechanical photocopying, recording or otherwise, without prior written permission of the publisher.

CommScope, 07-May-2020